



ITEM	QTY	DESCRIPTION
1	1	HOUSING
2	1	POWER CORD
3	1	CORD GRIP
4	1	LABEL
5	2	SWITCH SHAFT GROMMET
6	2	KNOB
7	1	SWITCH SEAL
8	1	CIRCUIT BOARD
+ 9	1	PUSHBUTTON SPACER
10	1	MOTOR, SUB ASSY
11	1-2	LEAD ASSY(2-REQ'D w/ TIMER)
*12	1-2	#10 INT. TOOTH LOCK WASHER
*13	1-2	#10-32 SCREW HEX HEAD SLOT
14	1	COVER
15	1	MOTOR SHAFT GROMMET
16	1	O-RING
17	4	#8-32 SCREW PAN HEAD
18	4	#8-18 SCREW SELF TAPING
19	1	REAR HEAD
20	2	FLANGED BEARING
21	1	ROTOR ASSY
22	1	TUBE ASSY
23	1	FRONT HEAD
24	2	THUMB KNOB
25	2	#10-32 SCREW SOCKET HEAD
26	2	#10-32 SCREW PAN HEAD
27	1	LABEL, DATA
*28	1	GREEN w/ YELLOW LEAD ASSY
33	1	POT SPACER
ACCESSORIES LIST		
40	1	VALVE(DUCK BILL)
41	1	VALVE BODY
43	4	COMPRESSION FERREL
44	4	COUPLING NUT
45	1	CLOSE NIPPLE SPECIAL
46	1	INJECTION BODY
47	1	STRAINER
48	15-FT	TUBING
60	1	INSERT, DUCK-BILL
61	2	GASKET, DUCK-BILL
TIMER OPTION		
50	1	TIMER
51	1	LEAD ASSY, WHITE/BLUE
52	1	LEAD ASSY, BLACK/BROWN




BACK CHECK VALVE AT PUMP HEAD


NOTE:
ACCESSORIES MAY BE ASSEMBLED
IN SEVERAL COMBINATIONS.
SEE MAINTENANCE MANUAL
FOR PROPER USAGE.



BACK CHECK VALVE, INLINE.



BACK CHECK VALVE AT INJECTION POINT



STRAINER ASSEMBLY with WEIGHT

NOVA-TECH
INTERNATIONAL

800 Rockmead Dr Ste 102 • Houston, TX 77339-2112
Tel: (281) 359-8538 • Toll Free Tel: (866) 433-6682
Fax: (281) 359-0084 • Toll Free Fax: (866) 433-6684
sales@novatech-usa.com • www.novatech-usa.com